

WONG JIA XI B032310495

BITS 3S1G2

INTERNET TECHNOLOGY

Windows IP Configuration

Host Name : LAPTOP-5TVEQFQP
Primary Dns Suffix :
Node Type : Hybrid
IP Routing Enabled. : No
WINS Proxy Enabled. : No

Ethernet adapter Radmin VPN:

Connection-specific DNS Suffix . :
Description : Famatech Radmin VPN Ethernet Adapter
Physical Address. : 02-50-82-A5-68-FE
DHCP Enabled. : No
Autoconfiguration Enabled : Yes
IPv6 Address. : fd fd::1a55:9543(Preferred)
Link-local IPv6 Address : fe80::ded0:de23:6770:ba11%8(Preferred)
IPv4 Address. : 26.85.149.67(Preferred)
Subnet Mask : 255.0.0.0
Default Gateway : 26.0.0.1
DHCPv6 IAID : 889344130
DHCPv6 Client DUID. : 00-01-00-01-2F-68-48-B4-30-F6-EF-77-7B-

DA

NetBIOS over Tcpip. : Enabled

Wireless LAN adapter Local Area Connection* 1:

Media State : Media disconnected
Connection-specific DNS Suffix . :
Description : Microsoft Wi-Fi Direct Virtual Adapter
Physical Address. : 30-F6-EF-77-7B-DB
DHCP Enabled. : Yes
Autoconfiguration Enabled : Yes

```

Wireless LAN adapter Local Area Connection* 2:

    Media State . . . . . : Media disconnected
    Connection-specific DNS Suffix . : 
    Description . . . . . : Microsoft Wi-Fi Direct Virtual Adapter
#2
    Physical Address. . . . . : 32-F6-EF-77-7B-DA
    DHCP Enabled. . . . . : No
    Autoconfiguration Enabled . . . . : Yes

Wireless LAN adapter Wi-Fi:

    Connection-specific DNS Suffix . : 
    Description . . . . . : Intel(R) Wi-Fi 6 AX201 160MHz
    Physical Address. . . . . : 30-F6-EF-77-7B-DA
    DHCP Enabled. . . . . : Yes
    Autoconfiguration Enabled . . . . : Yes
    IPv4 Address. . . . . : 192.168.1.104(Preferred)
    Subnet Mask . . . . . : 255.255.255.0
    Lease Obtained. . . . . : Friday, March 27, 2026 9:43:42 PM
    Lease Expires . . . . . : Saturday, March 28, 2026 9:43:42 PM
    Default Gateway . . . . . : 192.168.1.1
    DHCP Server . . . . . : 192.168.1.1
    DNS Servers . . . . . : 1.1.1.1
                           1.0.0.1
    NetBIOS over Tcpip. . . . . : Enabled

```

```

C:\Users\User>ping www.utm.edu.my

Pinging www.utm.edu.my [172.67.72.33] with 32 bytes of data:
Reply from 172.67.72.33: bytes=32 time=87ms TTL=59
Reply from 172.67.72.33: bytes=32 time=99ms TTL=59
Reply from 172.67.72.33: bytes=32 time=86ms TTL=59
Reply from 172.67.72.33: bytes=32 time=102ms TTL=59

Ping statistics for 172.67.72.33:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 86ms, Maximum = 102ms, Average = 93ms

```

```

C:\Users\User>msg * /server:192.168.1.105
'msg' is not recognized as an internal or external command,
operable program or batch file.

```

Msg command is not available for my Windows edition. This is common on Windows 11 Home, the msg command is only available on Windows Pro/Enterprise.

Notes

Self Review Question 1

1. Hostname

Display computer name on the network.

2. Ipconfig.

Show IP address, Subnet mask, and gateway for all adapters.

Computer's IP address

IPv4: 192.168.1.104

IPv6: ffd::1a55:9543

Computer Name

LAPTOP-5TVERPQP

Router's IP Address

192.168.1.1

IP setting

Dynamic

DHCP Enabled.

MAC number

30-F6-EF-77-7B-PA

Public IP Address

180.75.252.199

Check with Friend's IP

address. Are they similar?

Why?

My friend IP address 180.75.233.134 is similar to my laptop IP address.

They share same prefix 180.75.X.X which means they are same ISP.

3. ping — Test reachability of a host by sending ICMP packets and measuring round trip time.

request time out — reachable but not responding.

destination host unreachable — packet couldn't reach destination.

Notes

4. pathping

Combine ping and tracerf.

5. msg

Send message to other user on same network/LAN.

6. Traceroute

Show every router hop from your PC to destination

7 hops to fink website.

PC (192.168.1.104)

↓

192.168.1.1

↓

100.99.127.254

↓

10.232.65.54

↓

* * *

↓

13335.sgw.equinix.com (27.111.228.132)

↓

172.69.117.55

↓

104.26.14.166

Notes

7. `arp` — Displays / modifies the ARP table
8. `netstat` — Show NetBios over TCP/IP statistics and ~~net~~ tables.
name
9. `netstat` — Displays active TCP connections, listening ports, and networking statistics.
10. `nslookup` — Queries DNS servers to resolve hostnames to IP addresses.
11. `route` — Displays / modifies IP routing table.
12. `netview` — List computers and shared resources visible on local network.

Notes Self Review question 2.

1. Why we need port numbers?

- A PC can run many task at same time.
- port numbers allows OS to direct incoming network traffic to correct application.

2. Common Port Num

Application	Port Num
FTP	21
HTTP	80
HTTPS	443
Email - SMTP	25
Email - POP3	110
Telnet	23
SSH	22
DNS	53